

RANGEHOOD

60cm Stainless Steel Canopy

PRODUCT CODE: **EA60SX3**



FEATURES:

- + Stainless steel finish
- + 3 speed motor
- + 700m³/hr extraction capacity
- + 2 x 1w LED lights
- + Separate light function
- + Electronic button front controls
- + Dishwasher safe cassette filters
- + 150mm air flow outlet

KEY FEATURES

3 SPEED MOTORS

This rangehood provides the option of 3 different speed levels ensuring you have the option to use your rangehood at a low, medium or high level of operation.

EXTRACTION CAPACITY

The extraction capacity of 700m³/hr provides strength and power to this stylish rangehood.

DISHWASHER SAFE CASSETTE FILTERS

The cassette filters can be placed in a dishwasher for easy cleaning and can be easily removed and re-connected from the rangehood.

SPECIFICATIONS

Electrical Requirements	Rangehood is supplied with 10amp cord & plug.
Decible Rating	58-62 dBA
Available Ventilation Kits	RHKE65EU RHKMR65EU RHKTR65EU
	Wall - Eave vent kit Universal metal roof kit (includes flashing) Universal tile roof kit (includes flashing)
Rangehood Extension	Flue Extension 1m Code: ERCEXT
Carbon Filter	CF110 (requires 2)
Weight	8.4kg (Gross) / 7.0kg (Net)
Product Dimensions	W600mm x D450mm x H590/970mm
Shipping Dimensions	W660mm x D520mm x H250mm
Barcode	9347726044088



euro cooking

3 YEAR WARRANTY

SAFETY INFORMATION

- The Rangehood should be installed between 650mm to 750mm above the cooktop.
- The practice of venting a range hood exhaust into a ceiling space or wall cavity is not sound. Over time, pollutants such as grease and oil can build up, creating a fire hazard, along with associated odours and potential damage to insulation and the like.
- Equip your kitchen with a Fire Extinguisher and Fire Blanket. Refer to the supplied Product Manual for further safety information.

CLEANING AND MAINTENANCE


- Cleaning must only be carried out when the rangehood is turned off.
- Abrasive cleaners or sharp objects will damage the appliance surface. Only use warm water with a little washing-up liquid.
- The cassette mesh filters should be cleaned regularly, around every 2 months or more. Clean by soaking them in hot water, degreaser (or dish soap), and baking soda for 15-30 minutes, then scrub with a soft brush, rinsing, and drying completely. For general maintenance, dishwasher-safe aluminium filters can be washed monthly on a hot cycle.

RANGEHOOD USAGE

- Rangehoods generally work on the principle of an electric exhaust fan being located above the cooktop that extracts fumes and pollutants from the cooking area, via a filter membrane that catches vapours containing grease and oils. Once filtered, the air is either recirculated back into the kitchen area or discharged to an external air space.
- They effectively remove strong odours from cooking, preventing them from lingering in the home.
- Leave your rangehood run for a few minutes after cooking to help remove all odours and steam.

INSTALLATION DIAGRAM

- Installation by a qualified trades person is highly recommended. Please refer to the supplied Product Manual for full installation



CUSTOMER SUPPORT TOLL-FREE **1800 440 335**

Disclaimer: Please note the measurements and model appearances may change at any time. Euro Appliances reserves the right to change the specifications without notice.

www.euroappliances.au
cooking | laundry | refrigeration | alfresco